


10 TON BODY REPAIR KIT

SPARE PARTS LISTING

HYDRAULIC BODY & FRAME PUMP



KEY No	PART No.	DESCRIPTION
P01	10 - P01	Pump housing
P02	10 - P02	Filter
P03	10 - P03	Seal
P04	10 - P04	Pump reservoir
P05	10 - P05	Reservoir end cap
P06	10 - P06	Pump foot
P07	10 - P07	Hex nut
P08	10 - P08	O-ring
P09	10 - P09	Dip stick assembly
P10	10 - P10	Ball valve
P11	10 - P11	Ball valve
P12	10 - P12	Spring
P13	10 - P13	Overload screw
P14	10 - P14	O-ring
P15	10 - P15	Release valve stem assembly
P16	10 - P16	Seal
P17	10 - P17	O-ring
P18	10 - P18	Clamping nut

KEY No	PART No.	DESCRIPTION
P19	10 - P19	O-ring
P20	10 - P20	Piston
P21	10 - P21	Handle bracket
P22	10 - P22	Piston Pin
P23	10 - P23	Bracket cap
P24	10 - P24	Circlip
P25	10 - P25	Pump handle
P26	10 - P26	Handle grip
P27	10 - P27	Hose
P28	10 - P28	Coupling
P29	10 - P29	Dust cap
P30	10 - P30	Steel ball
P31	10 - P31	Spring plunger
P32	10 - P32	Spring
P33	10 - P33	O-ring
P34	10 - P34	Screw (safety valve)
P35	10 - P35	Plastic cap