


PARTS BREAKDOWN




PARTS LIST

No.	Description	Qty.
1	Body Assembly	1
2	Hitch Assembly	1
3	Bolt M8*20	8
4	Washer 8	14
5	Lock Nut M8	17
6	Bolt M8*90	4
7	Large Presto Pin	1
8	Hitch Pin	1
9	Anti-Tilt Device	1
10	Nut M10	2
11	Bolt M10*45	2

No.	Description	Qty.
12	Presto Pin	2
13	Pin	2
14	Support Brace	2
15	Bolt M8*70	3
16	Bolt M8*45	2
17	Ramp	1
18	Reflector	2
19	Spring Washer 5	4
20	Nut M5	4
21	Plug	1

RÉPARTITION DES PIÈCES



LISTE DES PIÈCES

N°	Description	Qté
1	Corps	1
2	Attelage	1
3	Boulon M8*20	8
4	Rondelle 8	14
5	Écrou de blocage M8	17
6	Boulon M8*90	4
7	Grande goupille rapide	1
8	Goupille d'attelage	1
9	Dispositif anti-bascule	1
10	Écrou M10	2
11	Boulon M10*45	2

N°	Description	Qté
12	Goupille rapide	2
13	Goupille	2
14	Renfort d'appui	2
15	Boulon M8*70	3
16	Boulon M8*45	2
17	Rampe	1
18	Réflecteur	2
19	Rondelle à ressort 5	4
20	Écrou M5	4
21	Fiche	1