



PARTS BREAKDOWN



PARTS LIST

No.	Description	Qty.
1	Switch Button	1
2	Cap	1
3	Upper Mechanism	1
4	Lower Mechanism	1
5	Connector Assembly	1
6	Steel Spring	1
7	Contact Plate	1
8	POM Spring	1
9	Battery Compartment	1
10	Battery Cover	1
11	Sleeve	1
12	Battery Lid	1
13	Motor	1
14	Coupler	1
15	3-way Connector	1
16	Hose Clamp	1
17	Discharge Hose	1
18	Funnel	1
19	Suction Tube	1
20	Rod	1
21	Tube Connector	1
22	Vane	1
23	Button Holder	1
24	Screw	2

RÉPARTITION DES PIÈCES



LISTE DES PIÈCES

N°	Description	Qté
1	Bouton d'interrupteur	1
2	Capuchon	1
3	Mécanisme supérieur	1
4	Mécanisme inférieur	1
5	Ensemble de connecteur	1
6	Ressort en acier	1
7	Plaque de contact	1
8	Ressort POM	1
9	Compartiment à piles	1
10	Couvercle de piles	1
11	Manchon	1
12	Couvercle de batterie	1
13	Moteur	1
14	Coupleur	1
15	Connecteur à 3 voies	1
16	Collier de serrage pour tuyau	1
17	Tuyau de refoulement	1
18	Entonnoir	1
19	Tube d'aspiration	1
20	Tige	1
21	Raccord de tube	1
22	Palette	1
23	Dispositif de retenue de bouton	1
24	Vis	2