



PARTS BREAKDOWN



PARTS LIST

#	DESCRIPTION	QTY			
1	Platform	1	12	Outside Frame Roller	2
2	Bolt M12×50	2	13	Washer M20	4
3	Washer M12	10	14	Outside Lifting Arm	1
4	Saddle	2	15	Connect Pin	1
5	Adjustable Plate	2	16	Middle Bush	1
6	Bolt M10×25	2	17	Inside Frame Roller	2
7	Handle	1	18	Inside Lifting Arm	1
8	Lifting Screw	1	19	Bearing	2
9	Inside Fixing Spindle	1	20	Outside Fixing Spindle	1
10	Spring Block Ring	4	21	Fixing Nut	1
11	Base Plate	1	22	Locknut M6	1
			23	Inside Removable Spindle	1

RÉPARTITION DES PIÈCES



LISTE DES PIÈCES

#	DESCRIPTION	QTY
1	Plate-forme	1
2	Boulon M12x50	2
3	Rondelle M12	10
4	Selle	2
5	Plaque réglable	2
6	Boulon M10x25	2
7	Poignée	1
8	Vis de montée	1
9	Tige de retenue intérieure	1
10	Anneau de blocage à ressort	4
11	Plaque de base	1
12	Rouleau de cadre	2

	extérieur	
13	Rondelle M20	4
14	Bras de levage extérieur	1
15	Goupille de connexion	1
16	Douille centrale	1
17	Rouleau de cadre intérieur	2
18	Bras de levage intérieur	1
19	Roulement	2
20	Tige de retenue extérieure	1
21	Écrou de fixation	1
22	Contre-écrou M6	1
23	Tige amovible intérieure	1