



FOLDING WALL-MOUNT STORAGE RACK

SPECIFICATIONS

Number of Shelves	6
Load Capacity (lb)	660
Capacity per Shelf (lb)	110
Overall Dimensions (in.)	72L x 13-3/4W x 39-3/8H
Material	Steel
Colour/Finish	Black/blue
Mounting Type	Wall
Includes	Mounting hardware

SAFETY

WARNING! Read and understand all instructions before using this tool. The operator must follow basic precautions to reduce the risk of personal injury and/or damage to the equipment.

Keep this manual for safety warnings, precautions, operating or inspection and maintenance instructions.


1. Use the correct tool for the job. This tool was designed for a specific function. Do not modify or alter this tool or use it for an unintended purpose.
2. Operate in a safe work environment.
3. Do not exceed the rated load capacity.

UNPACKING

Remove the parts and accessories from the packaging and inspect for damage.

Make sure that all items in the parts list are included.

PARTS BREAKDOWN



PARTS LIST

#	DESCRIPTION	QTY
1	Mounting bar	2
2	Supporting screw	6
3	Flat washer $\phi 6$	6
4	Plastic dowels	6
5	Supporting bar	12
6	Lock nut M8	12
7	Flat washer $\phi 8$	12
8	Bolt M8	12

TROUBLESHOOTING

Visit a Princess Auto Ltd. location for a solution if the tool does not function properly or parts are missing. If unable to do so, have a qualified technician service the tool.



SUPPORT DE RANGEMENT

PLIABLE À MONTAGE MURAL

SPÉCIFICATIONS

Nombre de tablettes	6
Capacité de charge (lb)	660
Capacité par tablette (lb)	110
Dimensions hors tout (po)	72 (long.) x 13 3/4 (larg.) x 39 3/8 (haut.)
Matériau	Acier
Couleur/fini	Noir/bleu
Type de montage	Mural
Comprend	Quincaillerie de montage

SÉCURITÉ

AVERTISSEMENT ! Veuillez lire et comprendre toutes les instructions avant d'utiliser cet outil. L'utilisateur doit respecter les précautions de base lorsqu'il utilise cet outil afin de réduire le risque de blessure ou de dommage à l'équipement.

Conservez ce manuel qui contient les avertissements de sécurité, les précautions, les instructions de fonctionnement ou d'inspection et d'entretien.


1. Utilisez le bon outil pour la tâche à effectuer. Cet outil a été conçu pour une utilisation spécifique. Évitez de modifier ou d'altérer cet outil ou de l'utiliser à une fin autre que celle pour laquelle il a été conçu.
2. Travaillez dans un environnement de travail sécuritaire.
3. Ne pas dépasser la capacité de charge nominale.

DÉBALLAGE

Retirez les pièces et les accessoires de l'emballage et vérifiez s'il y a des dommages.

Assurez-vous que tous les articles sur la liste de pièces sont compris.

RÉPARTITION DES PIÈCES



LISTE DES PIÈCES

N°	DESCRIPTION	QTÉ
1	Barre de montage	2
2	Vis porteuse	6
3	Rondelle plate $\phi 6$	6
4	Goujons en plastique	6
5	Barre d'appui	12
6	Contre-écrou M8	12
7	Rondelle plate $\phi 8$	12
8	Boulon M8	12

DÉPANNAGE

Si l'outil ne fonctionne pas correctement ou si des pièces sont manquantes, visitez un magasin Princess Auto Ltd. afin de trouver une solution. Si ce n'est pas possible, demandez à un technicien qualifié de réparer l'outil.